



Forma Bella


Villeroy & Boch
 1748

	CM.	UV.	
Piatto piano	29	6	3300136812
Piatto piano	27	12	3300136814
Piatto piano	24	12	3300136817
Piatto piano	21	12	3300136821
Piatto fondo	23	12	3300136819
Tazza caffè lt.0,10		12	3300136825
Piattino caffè	12	12	3300136837
Tazza the lt.0,18		12	3300136839
Tazza colazione lt.0,22		12	3300136841
Piattino the/colazione	15	12	3300136842
Coppetta	12	12	3300136850
Piatto tondo	32	6	3300136848
Coppetta zucchero	12	12	3300176883



Forma Easy


Villeroy & Boch
 1748

	CM.	UV.	
Piatto piano	29	6	3300083894
Piatto piano	27	12	3300083897
Piatto piano	24	12	3300083898
Piatto piano	21	12	3300083900
Piatto piano	16	12	3300083902
Piatto fondo	23	12	3300083903
Tazza caffè svas. lt.0,10		12	3300083907
Tazza caffè imp. lt.0,10		12	3300083906
Piattino caffè	12	12	3300083908
Tazza colaz.svas.lt.0,27		12	3300083912
Tazza the imp.lt.0,22		12	3300083919
Piattino the/colazione	15	12	3300083899
Caffettiera lt.0,30		6	3300083933
Theiera lt.0,40		6	3300083935
Coppetta	15	12	3300083966
Coppetta	9	12	3300083968
Cremierina lt.0,14		12	3300083938

Bianco