


FORMA BUCKINGHAM BIANCA




Forma BUCKINGHAM	CM.	UV.	
Piatto piano	31	12	3051800500
Piatto piano	28	12	3051800400
Piatto piano	24,5	24	3051800100
Piatto piano	21	24	3051800300
Piatto piano	18,5	24	3051800320
Piatto piano	16,5	24	3051800330
Piatto fondo	23	24	3051800200
Ovale	30,5	12	3051802200
Ovale	25,4	12	3051802100

Forma BUCKINGHAM	CM.	UV.	
Ovale	20,3	12	3051802000
Coppetta	18	24	3051801000
Mezzaluna	21	12	3051803000
Vaso fiori	6	3051804000	
Tazza caffè cl. 11,2		24	3151800100
Piatto caffè	13,4	24	3151800110
Tazza the cl. 21		24	3151800120
Piatto the	15,2	24	3151800121
Tazza consommè senza manici cl. 30	38,5	24	3151800200



Decoro PRAGUE	CM.	UV.	
Piatto piano	31	6	3051972000
Piatto piano	27	12	3051970100
Piatto piano	21	12	3051970300
Piatto fondo	23	12	3051970200
Ovale	31	12	3051971000
Insalatiera	24	12	3051973000
Coppetta	15,5	12	3051974000
Salsiera cl.32,5	1	3051975000	
Set 3 pezzi the servire	1	3051979000	
Tazza caffè con piatto cl. 11		6	3151970100
Tazza the con piatto cl. 22,5		6	3151970200
Mug cl. 35	35	6	3151970300



Decoro APPLEBEE	CM.	UV.	
Piatto piano	31	6	3051982000
Piatto piano	27	12	3051980100
Piatto piano	21	12	3051980300
Piatto fondo	23	12	3051980200
Ovale	31	12	3051981000
Insalatiera	24	12	3051983000
Coppetta	15,5	12	3051984000
Salsiera	1	3051985000	
Vaso fiori	1	3051986000	
Brocca cl. 125	1	3051987000	
Set 3 pezzi the servire	1	3051989000	
Tazza caffè con piatto cl. 11		6	3151980100
Tazza the con piatto cl. 22,5		6	3151980200
Mug cl. 35	6	3151980300	